

Operator: Validation Manager Vessel: Cooker Cooler  
Process: Validation Product: Food  
Session Start: 22-11-2013 09:26:18 Time Zone: UTC offset 01:00:00  
Session Stop: 22-11-2013 09:26:33  
Session Name: Cooker Cooler Validation  
Session Text:



## Limit Report

Name: Limit Report Shell#1  
Description: Steriphase 1

### Input parameters

Criteria: Passed when 129,00 °C < Value  
Triggering : All, Temperature  
Data Series: ENVIRONMENT

### Range

Time: 16-09-2010 15:33:34 to 15:43:48

### Triggering Interval

from	to
16-09-2010 15:35:20	16-09-2010 15:37:50
16-09-2010 15:38:10	16-09-2010 15:43:40

Summary Time: **00:08:00**

Operator: Validation Manager Vessel: Cooker Cooler  
Process: Validation Product: Food  
Session Start: 22-11-2013 09:26:18 Time Zone: UTC offset 01:00:00  
Session Stop: 22-11-2013 09:26:33  
Session Name: Cooker Cooler Validation  
Session Text:



## Limit Report

Name: Limit Report Shell#2  
Description: Steriphase 2

### Input parameters

Criteria: Passed when 129,00 °C < Value  
Triggering : All, Temperature  
Data Series: ENVIRONMENT

### Range

Time: 16-09-2010 15:43:48 to 15:54:24

### Triggering Interval

from	to
16-09-2010 15:43:50	16-09-2010 15:54:20

Summary Time: **00:10:30**